




TRIGGER LOCK INSTRUCTIONS



1. Using a ballpoint pen, push in the set pin and hold.
2. Turn the dials one at a time to set your own combination.
3. Release the set pin after your code is set.
4. Now your trigger lock is set.
5. NOTE: code can only be changed if the correct code is showing which will allow you to change it.